

# AWILCO

## IMDBOX

---

## USER MANUAL



Please be sure to read and save the entire manual before using the energy system. Misuse may result in damage to the unit and/or cause harm or serious injury.

**PLEASE KEEP THE MANUAL  
FOR FUTURE REFERENCE**

### SERVICE AND CONTACT INFORMATION

---

Email: [mail@awilco.dk](mailto:mail@awilco.dk)

---

Phone: +45 56 56 54 00

---

Web: [awilco.dk](http://awilco.dk)

---

 **AWILCO**  
FLEXIBLE POWER SOLUTIONS

For safe and optimum performance, the **IMDBOX** must be used properly. Carefully read and follow all instructions and guidelines in this manual and give special attention to the **CAUTION** and **WARNING** statements.

**PLEASE KEEP THIS MANUAL  
FOR FUTURE REFERENCE**

**DISCLAIMER**

---

While every precaution has been taken to ensure the accuracy of the contents of this guide, **AWILCO ApS** assumes no responsibility for errors or omissions. Note as well that specifications and product functionality may change without notice.

**IMPORTANT**

---

Please be sure to read and save the entire manual before using the **IMDBOX**. Misuse may result in damage to the unit and/or cause harm or serious injury. Read manual in its entirety before using the unit and save manual for future reference.

**SERVICE CONTACT INFORMATION**

---

Email: [mail@awilco.dk](mailto:mail@awilco.dk)

---

Phone: +45 56 56 54 00

---

Web: [awilco.dk](http://awilco.dk)

---

**DOCUMENT PART NUMBER**

---

IMDBOX Rev A

05.2024



# TABLE OF CONTENTS:

---

<b>1. PRODUCT DESCRIPTION:</b>	<b>4</b>
<b>2. APPLICATION:</b>	<b>5</b>
<b>3. INSTALLATION:</b>	<b>6-8</b>
3.1 Startup of Connection	8
<b>4. TEST/RESET FUNCTION:</b>	<b>9</b>
<b>5. FAULT CODE AND TROUBLE SHOOTING:</b>	<b>10</b>
5.1 LED lights in IMD relay	10
5.2 Fault (Yellow LED in IMD)	10
5.3 SETTINGS on IMD relay	10
5.4 Self Test IMD	10
<b>6. WARRANTY AND CE MARKING:</b>	<b>11</b>

---

# 1. PRODUCT DESCRIPTION:

The intended use of this IMDBOX is to ensure electrical safety when using an AC 230V energypower systems, e.g. mobile inverters- or generators run by fossil fuel inside a vehicle, by the means of protective measure“. Protective separation with insulation monitoring and disconnection“. All essential components are included in the IMDBOX ready-to-connect safety distribution box.

The safety distribution box is also suitable for retrofitting purposes of e.g. existing AWILCO energypower systems.

To provide the highest safety, the AWIMDBOX is equipped with both a combi C 16A/30mA RCBO protection relay (RCD type A acc. to IEC 61009), and an Isolation Monitoring Device (IMD acc. to IEC 61557-8) combined with a 16A contactor.

The combination of both the protective separation (in practice an unearthed system, also called an isolated system or an IT-system) and the integrated protective devices mentioned above, gives a safe environment for end users of AC 230V, both inside and outside vehicles equipped with AC 230V systems connected to the IMDBOX.



**F1 = RCBO**

**Q1 = CONTACTOR**

**Q2 = ISOMETER**

## 2. APPLICATION:

The integrated IMD in the IMDBOX continuously monitors the insulation resistance of the unearthed system (IT-system / isolated system). The currently measured insulation resistance is indicated on the built-in diode-LED of the IMD. In this way, changes such as the connection of loads via the socket(s) can easily be visual detected, through the transparent hatch in the electrical switchboard.

An advantage of an IMD is that the standard requires, that it must support a prescribed measuring principle which enables the IMD to monitor both symmetrical and asymmetrical deteriorations in insulation.

The definition of a symmetrical deterioration in the isolation level can be said to occur, when the insulation resistance of all conductors in the

system to be monitored, declines to approx. the same extent. An asymmetrical isolation deterioration can be said to occur when the isolation resistance, e.g. of a conductor, declines to a significantly greater extent than that of the other conductor(s) in the system.


If an overload or a short circuit occurs e.g. in a consumer load connected to the IMDBOX via the socket(s), the RCBO will be activate, and herby automatically provide disconnection of the AC 230V output supply. Correspondingly, if an isolation fault (a first fault) of less than  $23k\Omega$  occurs, the IMD inside the IMDBOX will also activate a disconnection of the AC 230V output supply, via the built-in contactor. At the same time, the alarm diode in the IMD will light up as a visual alarm.

### 3. INSTALLATION:

Only qualified and/or skilled personnel are allowed to install the IMDBOX.

The IMDBOX only protects one AC 230V source/socket.

**If the AC 230V source/socket inside the vehicle has multiple sockets, you have to blind ALL others than the one connected to the IMDBOX.**




### 3. INSTALLATION:

**CAUTION:** Always switch off all equipment before installing.

#### START UP CONNECTION

- When IMDBOX is installed, use ground cable (Yellow/green) in both ends (FIXED).
  - "FIXED" means no sockets are attached, the user chooses what type of socket he want to mount, SHUKO, UK socket etc.
- IN: Input-cable from the AC 230V source inside the vehicle (e.g. Inverter, Power system, generator etc.)
  - OUT: Output from AWIMDBOX, providing safe AC 230V to power tools or distributor plugs.



### 3. INSTALLATION:



**IMPORTANT!**  
All equipment attached to IMDBOX after SHUKO socket/UK Socket has to have earth wiring.



## 4. TEST/RESET FUNCTION:

**When the IMDBOX detects an insulation fault, it will disconnect the AC 230V output.**

### PROCEDURE TO RESET

1. Unplug the connected power tool
2. Open the IP65 hatch on the IMDBOX
3. Press the T/R button on the yellow (Q2) IMD relay until it resets (approx. 3 seconds).  
The T/R button is the test/reset button on the IMD relay.
4. Close the hatch and ensure the power tool is safe to use before re-connected.

**The TEST button on the IMD relay can also be activated for test purposes, if needed.**



T/R = TEST / RESET

# 5. FAULT CODE AND TROUBLE SHOOTING:

## LED LIGHTS IN IMD RELAY

---

1. If only the green ON-LED lights, the system are OK, the IMD covers the system = NO fault.
2. In the event of the yellow-LED lights, there is an earth fault present!! (STOP) Disconnect/unplug the connected power tool from AWIMDBOX).
3. Go to the Procedure to RESET.

## FAULT (YELLOW LED IN IMD)

---

1. Disconnect the connected power tool from IMDBOX
2. Search and find fault before using the AWIMDBOX.

**CAUTION: NEVER press the T/R button before a fault is found and repaired.**

## SETTINGS ON IMD RELAY

---

The settings in the IMD relay are preinstalled from AWILCO and **must not be modified.**

## SELF TEST IMD

---

When AWIMDBOX is installed correctly, the IMD inside the box will do a self-test.

The IMD will make a self-test every time the AWIMDBOX has been disconnected from AC 230V and reconnected to AC 230V again.

## 6. WARRANTY AND CE MARKING:

The warranty of this product follows the normal rules for B2B in and outside of Europe.

Awilco' CE mark for this product covers the AWIMDBOX, its components and its internal electrical wiring in the IP65 box, as long as no mechanical and/or electrical changes are made to this switchboard.

